

FIG. 1

EL575423 0850S

C15CO-3168

200

202

oper1 Password = "abc^123"

Service-Type = Login

204 - Cisco: AVPair = "shell:cmd-expr=show .\*",

206 - Cisco: AVPair = "shell:cmd-expr=telnet 10\14\0\.[0-9]+",

208 - Cisco: AVPair = "shell:cmd-expr=ping .\*"

F16.2





Fig. 3

EL575423085US

018LC-3168



F16.4